



Operation of Accor Flowtite valve:

- Hold body with one hand and pull to cut flow of water to fixtures
- Hold body with one hand and push valve in to release flow of water

Benefits of Accor Flowtite:

- 10-year manufacturer's warranty on labor and materials



How To: Valve Operation

**ACCOR CUSTOMER
SERVICE**

**CUSTOMER CARE
WARRANTY REQUEST**